

# IceGuard®

## SUMP PUMP DISCHARGE SYSTEM

Sump pump discharge pipes are outside and will freeze in winter. IceGuard® allows water to escape if pipes freeze or become blocked for any reason. Without it, your basement will flood in winter even though your sump pump is running!

PN 11240



**Basement  
Systems**  
Basement Environment Specialists®



The patented design of the IceGuard® System automatically allows water to escape through its openings. This unique feature provides an exit when pipes are blocked, usually by ice or snow.



IceGuard saved this basement from flooding!

- Allows water to escape if pipe freezes or becomes blocked for any reason – in turn allows your sump pump to keep your basement dry in winter
- 100% automatic – nothing for you to do
- When it's not freezing outside, no water escapes through the IceGuard
- Openings are a unique, patented\* feature that provide an exit for the water